

SETTING UP THE DVR.

PRESS THE SETUP BUTTON

GO TO SYSTEM

GO TO NETWORK

CHANGE THE IP SETTING TO DHCP

PRESS THE OK BUTTON.

PRESS THE EXIT BUTTON TWICE. (COMPLETELY OUT OF THE MENU)

GO BACK TO THE NETWORK.

CHANGE THE IP SETTING TO STATIC.

IF YOU DON'T SEE ANYTHING FOR GATE WAY, PLEASE MANUALLY
PUNCH IN 192.168.1.1 (OR YOUR ROUTER'S IP ADDRESS) FOR THE GATEWAY.

PRESS THE OK BUTTON.

PRESS THE EXIT BUTTON TWICE. (COMPLETELY OUT OF THE MENU)

REMEMBER THE DVR'S IP ADDRESS.

SETTING UP THE ROUTER.

PORT FORWARDINGOPEN PORT # 9013 and #80

MAKE SURE DMZ SETTING IS DISABLED.

CHECK THE SECURITY. FOR THE LYN SYS ROUTERS, DISABLE
ANONYMOUS INTERNET REQUEST UNDER THE SECURITY.